Mini Configuration Software

Take control of your AJA Mini-Converters with the new Mini Config software; a cross-platform application that enables you to view and modify Mini-Converter settings via a standard USB connection to a computer.


Simple

The Mini Config software requires no installation. Just connect a Mini-Converter to the computer and run the Mini Config software. The connected device is automatically recognized and the relevant configuration options for that device are displayed.

The Mini Config interface is direct and to-the-point; providing access to all converter settings using pull down menus grouped logically together into separate tabs.

Visual

An image of the connected Mini-Converter is displayed in the top portion of the interface, allowing you to see at a glance what device you are configuring and the status of each connection.



The Mini Config interface provides at-a-glance status and configuration information for the selected converter.

Remote

You can control any number of Mini-Converters from a single computer using the same Mini Config software application. The device selection pull down in the upper right of the interface allows you to choose which device to affect. Because control is handled through the USB interface, reconfiguring a converter can be done without having to access the DIP switches on the unit. This is particularly useful for rack-mounted installations or situations where access to the converter is limited.

