



# ECLPRL19BK

## EXPLODED VIEW AND PART LIST





 <b>PROLIGHTS</b>		<b>SPARE PARTS DIAGRAM</b>	
CODE <b>ECLPRL19BK</b>		ASSEMBLY <b>GENERAL ASSEMBLY</b>	
DATE <b>10/11/2022</b>	REVISION N. <b>02</b>	SHEET <b>01 01</b>	FORM <b>A4</b>
<small>           Prolights is a trademark of Music &amp; Lights S.r.l. Via A.Olivetti, snc - 04026 - Minturno (LT) - Tel. +39 0771 72190 - info@prolights.it            Duplication of this drawing, either full or in part, is strictly prohibited without prior written authorization of Music&amp;Lights.         </small>			

**ECLPRL19BK - GENERAL ASSEMBLY**

<b>Item</b>	<b>Part code</b>	<b>Description</b>	<b>Qt</b>
2	A220101329AA	FRONT LENS FIXING PLATE	1
3	A08010007200	FRONT LENS-19	1
4	A220101328AA	FRONT LENS HOLDER	1
5	A07010005600	HEXAGON PILLAR	4
6	A07010005700	HEXAGON PILLAR	4
7	A08010007300	MIDDLE LENS-19	1
8	A220101327AA	MIDDLE LENS HOLDER	1
9	A220101326AA	BACK LENS FIXING PLATE	1
10	A08010007400	BACK LENS-19	1
11	A220101325AA	BACK LENS HOLDER	1
12	A20090000900	SPRING	1
13	A20090000800	HEXAGONAL COPPER COLUMN	1
14	A040400015C0	LENS COVER-RIGHT SIDE	1
15	A060100321C0	SLIDER OF FOCUSING	8
16	A14020015500	SCREW NUT	2
17	A14020024300	SCREW	2
18	A040400016C0	LENS COVER-LEFT SIDE	1
19	A03010017500	BACK LENS-26	2