



MONOLYTE

MOBILE UNIBODY SCREEN SYSTEM

"As we travelled the country visiting our customers, one thing became clear. **There is a gap in the market when it comes to small meeting room screens.** We believe we have accomplished this in a great system, that even I can set up by myself in three minutes."

- Todd Liedahl, President, AV Stumpfl Inc.



MODERN LOOK



NO TOOLS
REQUIRED



QUICK AND
INTUITIVE SET UP



COST EFFECTIVE



SETUP

INTUITIVE. SIMPLE. SAFE.

Setting up a Monolyte projection screen is as simple as it sounds even for low utilization users.



1. Scope of delivery: Monolyte frame with snap joints and integrated legs, screen material, bag for projection screen, case (softbag, frame bag or flight case), manual.



2. Folded Monolyte frame. High precision extruded aluminum profiles and snap joints define the skeleton of the projection screen. No parts can get lost and set up is intuitive.



3. Set the screen so that the legs are placed towards the ground.



4. Unfold the frame along the horizontal bars. The snap joints will engage automatically.



4. Unfold the leg elements to both sides and close the hinges.



1. Lay out the surface on the frame with the label „OBEN-TOP“ corresponding with the upper frame bar.



7. Press on the projection surface by starting at one corner and fasten the buttons one by one.



8. Put the screen upright, unfold the rear leg bars and lock the hinges.



9. Unpack the skirt and attach it to the double studs on the bottom of the projection surface and along the lateral sides of the legs.

Monolyte is available in different standard sizes:

Overall size	Leg Height size	Picture size
6'8"W x 7'H	3'	6'W x 3'4"H
7'10"W x 7'8"H	3'	7'2"W x 4'H
8'4"W x 8,6"H	3'6"	7'8"W x 4'4"H
9'5"W x 9'1"H	3'6"	8'9"W x 4'11"H

*Overall size includes integrated leg height.